

# ZeroFlush Waterless Urinal Commissioning Instructions for Odour Barrier Oil System

**Before commissioning a urinal for use, ensure;**

- **You have performed a water test to check for any leaks**
- **Urinal lip height is correct according to AS3500.2-2015**
- **There are no blockages in your waste outlet pipe**



---

## STEP 1

Remove the new insert from the box and place it into position in the urinal housing

---



## STEP 2

Push the trap insert into position. You should feel a click as the O-Ring locks into place. Test for a good seal by trying to spin the trap insert

---



## STEP 3

Pour 1 Litre of water into the bowl of the urinal and allow it to drain into the housing.

Slowly pour **the entire contents of the odour barrier** onto the trap insert.

Wipe clean and the urinal is ready for use.

---